


8106824 D.H.W. Tank BS1S 750 I.



The exploded diagram is common to several finished products. The spare parts related to the selected code are only those listed below.

IMPORTANT: The use of non-original spare parts will void the warranty and may compromise the safety of the product.

Position	Code	Description	Note	Advised parts
001	7503406	Gasket diam.168 + screws		
002	7503407	Closed flange diam.185		
003A	7503402	Flange diam.170 + hole		
004B	6072711	Magn.anode diam.33x650 + plug		
005A	7503404	Thermometer 1/2"X100		
006	6317047	D.H.W sensor Housing 1/2"x95		
007C	7503400	Cover diam.950		
008	6072713	Magnesium anode diam.33x400		
	7503418	External insulating jacket		
	7503424	PVC covering		
	7503448	Washer kit		
	7503405	Earth cable		

A = Spare parts for minimum fittings